Reference 7040/250

Caliber R 27 PS



Self-winding wristwatch with minute repeater.
White gold.

Patek Philippe reinterprets its minute repeater for ladies with a refined new model, housed in a whitegold case with a slightly increased diameter (36 mm). The white-gold dial is hand-guilloched with a swirling pattern, and covered with a night-blue transparent enamel that lets the guilloché-work

shine through – an artisanal technique referred to as *flinqué* enamel. The stately look is crowned by a bezel with 168 brilliant-cut diamonds set in two staggered rows using the exclusive "Flamme®" technique. The self-winding caliber R 27 PS is visible through the sapphire-crystal caseback.

The minute repeater

On demand, the minute repeater strikes on two classic gongs the hours, the quarter-hours, and then the minutes that have elapsed since the last quarter-hour. The first hammer strikes the hours on the low-pitched gong with one strike for each hour. Subsequently, each quarter-hour is sounded as an alternating double strike by two hammers on both the high- and low-pitched gongs. For the first quarter-hour, a double-strike sequence is played; for the half-hour, two double-strike sequences; and for the third quarter-hour three double-strike sequences. Finally, the second hammer strikes the high-pitched gong to count the number of minutes that have passed since the last quarter-hour. At 12:59, the melody consists of 12 low sounds, 3 double high/low sounds, and 14 high sounds (totaling the maximum of 32 strikes).

Settings



- Before you perform any corrections or settings, wind the watch by hand (about 20 turns of the winding crown).
- Pull the crown out (1).
- Turn the hands forward.
- Push the winding crown home again (2).

Minute repeater

To activate the minute repeater, push the slide (3) all the way up. Now release it completely – do not pull it down. Two small hammers will now strike on two classic gongs the hours, quarter-hours, and minutes. If the watch was set aside unwound for an extended period of time, the minute repeater might not in-dicate the correct time on the first try. This may happen if the oil is not evenly distributed but bears no negative consequences. The striking mechanism will function correctly if you activate it two or three times in a row.

Caution:

- The strike sequence of the minute repeater must be allowed to end completely before it is activa ted again.
- Never actuate the winding crown as long as the repeater is working and for 30 seconds thereafter. Doing so could cause damage to the striking mechanism which would not be covered by the warranty.

Recommendations

WATER RESISTANCE

Although your watch is equipped with a waterresistant crown, it is not protected at all against the ingress of moisture because of the slot for the minute repeater slide.

Therefore, exercise care to ensure that liquid does not come into contact with your watch.

SERVICE

We recommend that you have your watch serviced at least once every three to five years. For this purpose, we suggest you take it to an Authorized Patek Philippe Retailer who will send it to our Geneva manufacture, the only location authorized to service watches with minute repeaters. You can then be assured that your watch will be inspected and overhauled by a qualified master watchmaker at Patek Philippe headquarters in Geneva.

The master watchmaker will completely disassemble the movement and then inspect, clean, and lubricate all the individual parts prior to reassembly. All functions of the watch will also be tested in detail and the escapement regulated if necessary. Finally, its rate accuracy will be monitored and precision-adjusted for a further period of at least two weeks.

The case and the buckle will be polished as per your instructions and your watch will be returned to you in mint condition. The entire process will take several weeks because each watch must undergo a complete series of tests to fulfill the strict quality criteria of Patek Philippe.

If you have any questions regarding the maintenance of your watch, contact the Authorized Patek Philippe Retailer nearest you or our International Customer Service department in Geneva, or visit www.patek.com.

WINDING

When it is on your wrist, your watch is wound automatically by your arm movements. When fully wound and off the wrist, your watch has a power reserve of at least 43 hours. If your watch stopped because you set it aside for an extended period of time, you can wind it manually with about 20 turns of the crown clockwise.

We advise you to wind the watch before you put it on. This way, you can avoid lateral pressures on the winding stem which, repeated, could damage the stem tube. The same applies to handsetting. Please use your fingernails to pull the crown out and turn it gently between two fingertips.

CHANGING THE CASE BACK

Your watch comes with a sapphire-crystal case back and a separate interchangeable solid metal back. Only qualified master watchmakers at the Patek Philippe workshops in Geneva are authorized to perform this change.

WATCH WINDER

Your self-winding wristwatch was presented to you in a case with a winder. Keep your watch in this winder if you do not intend to wear it for several days. The constant motion of the winder will keep your watch wound and no time or calendar adjustments will be needed when you put it on again.

PATEK PHILIPPE SEAL

The Patek Philippe Seal is a global emblem of quality that applies to the completed and fully cased watch. It covers the movement, the case, the dial, the hands, the pushers, the strap and bracelet, the clasp, as well as all other components that contribute to the accuracy and aesthetic appeal of a watch. It takes technical, functional, and design-related aspects into account and also covers the visual appearance of the watch, its rate accuracy and dependability, as well as the quality of the customer service to which its owner is entitled. It encompasses the entire know-how and the unique facets that govern the development, production, and long-term maintenance of an exceptional timepiece.

Movement technical data



CALIBER: R 27 PS
DIAMETER: 28 MM
HEIGHT: 5.05 MM
NUMBER OF PARTS: 342
NUMBER OF JEWELS: 39

POWER RESERVE: MIN. 43 HOURS - MAX. 48 HOURS WINDING ROTOR: GUILLOCHED 22K GOLD MINIROTOR,

UNIDIRECTIONALLY WINDING

BALANCE: GYROMAX®

FREQUENCY: 21,600 SEMI-OSCILLATIONS PER HOUR (3 HZ)

BALANCE SPRING: SPIROMAX ®

HALLMARK: PATEK PHILIPPE SEAL